

PTV2 buttons

MODE 0

info	channel info			<	left / down [#]	>	right / up [#]
FM	record	AM	stop	<>	up folder	clock	exit
mode	toggle mode 0/1			tone	audio	sel	menu
1	ok	4	tv/radio				
2	subtitle	5	favourites				
3	pause / left [#]	6	0 / right [#]				[#] Alternate function when rotary is disabled

MODE 1

info	channel info			<	left	>	right
FM	7	AM	8	<>	0	clock	pause
mode	toggle mode 0/1			tone	9	sel	menu
1	1	4	4				
2	2	5	5				
3	3	6	6				

LONG-PRESS

info	EPG			<	exit [§]	>	up folder [§]
FM	toggle rotary	AM	toggle idle timeout	<>		clock	
mode				tone	teletext	sel	power
1	red	4	blue				
2	green	5	yellow				
3	stereo (aux)	6	exit [§]				[§] Only for PTV boards after 12/2015

STEERING WHEEL

UP	UP (acts like CH-)
DOWN	DOWN (acts like CH+)

ADDITIONAL BUTTONS FOR 4:3 BOARD MONITOR

	MODE 0	MODE 1
RDS	EPG	down
TP	channel info	up
DOLBY	exit	pause

EXPLANATION

toggle rotary: When you long press FM, it will turn this feature ON or OFF. Turning the rotary off allows you to access the old blue BMW analog tuner menu, where you can adjust colour, contrast, TV standard etc.

toggle idle timeout: When you long press AM, it will turn this feature ON or OFF. Idle timeout means that the digital tuner will be powered OFF if left unused for longer than 30 seconds (e.g. if you are using FM radio instead). Turning the tuner off has the disadvantage of having to “reboot” it when next needed, which takes a short period of time.

www.pibus.info

2016.02.25